

# Can Am X3 Front Door Bag Install Instructions



Door bag kit includes a driver and passenger side bag and two phone/to go bags.



## STEP #1

The door bags can be installed with the doors on or off the vehicle. Remove the screws indicated by the red arrows below, this allows you to separate the plastic panel from the door frame making it easier to wrap the Velcro straps around the frame.



## STEP #2

Wrap the bottom Velcro straps around the frame and secure. Only over lap the Velcro strap indicated by the red arrow below 1/2". Replace the three screws that you removed in step #1.



## STEP #3

Wrap the top three Velcro straps around the frame and secure as shown below.



**SIMPSON**

**WEST COAST SEAT SALES**  
1405 W. 240th Street  
Harbor City, CA 90710

**Toll Free:** 800-929-7223 x122  
**Phone:** 310-325-6035 x122  
**Fax:** 310-320-7179

**WWW.TEAMSIMPSON.COM OR CALL (310) 325-6035**