

WEB INSTALLATION

Belt webbing must have an unobstructed travel path. Allow a minimum 1-inch space around the belts in the seat opening for anticipated travel. Your belts will move in the direction of the impact. Make sure this area is clear of obstruction. All edges including any seat holes must have an edge guard to protect the webbing against abrasion and cuts.

Keep belts away or protected from sources of heat (i.e., exhaust headers and welding).



UNDER NO CIRCUMSTANCES ARE BOLTS INSERTED THROUGH BELT WEBBING ACCEPTABLE FOR MOUNTING.

“**LOCKING**” the 3-Bar Slide Adjuster shown in Steps 1 through 4 is VERY IMPORTANT. The 3-Bar Slide Adjuster must be located as close as possible to the Bolt-in bracket or Roll Bar (in Wrap Around design).

Become familiar with the installation, use and operation of your restraint system. Call Simpson at 1-800-654-7223 with any questions.

WARNING :

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is **INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.** No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of Simpson.